



Charcoal Portable Barbecue with Fan Assisted Air Flow

PLEASE READ AND KEEP THESE INSTRUCTIONS FOR FUTURE USE

SAP Code: JB03300201

For further assistance, other products and more, join us at:

Website: www.firemountain.co.uk

Facebook: www.facebook.com/fire-mountain



Thank you for choosing our Fire Mountain Fan Assisted Charcoal Barbecue. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our customer service team on the details provided on the back page of this manual.

Warnings

READ THE INSTRUCTIONS BEFORE USE.

This product can only be used outdoors in a ventilated environment.

Never use this product indoors, as burning charcoal will cause carbon monoxide poisoning.

Maximum amount of charcoal required is 250g.

Do not cook before the fuel has a coating of Grey ash.

WARNING! This barbecue will become very hot, do not move it during operation.

Do not use indoors!

WARNING! Do not use spirit or petrol for lighting or re-lighting! Use only firelighters, Lighting Fluid or Lighting Gel which complies to EN 1860-3 regulations.

WARNING! Keep children and pets away.

Always wear barbecue gloves when grilling or adjusting the vents as well as when using a chimney starter.

When preparing food, adding charcoal and always wear barbecue gloves.

Caution: Rechargeable batteries cannot be used.

Caution: In order to avoid burns, always wear barbecue gloves.

Caution: The appliance will become very hot during use, please wear barbecue gloves.

Product Specifications

Easy and fast start with smart turbo fan structure.


Stainless steel grill rack.

Unique charcoal box design avoids fats and seasonings dripping into the charcoal.

Portable design for relocation and storage.


Easy to clean parts.

Product Parts




How to Use


1. Place 4pcs AA batteries inside the battery fan box (not supplied)




2. Fill the charcoal box with enough charcoal max 250g




3. Put Lighting Fluid or Lighting Gel on the ignition plate in a circle



4. Put the battery fan box into the base of the main body




5. Light the Lighting Fluid or Lighting Gel using a long nose lighter or safety matches



6. Put the charcoal box over the ignition plate



7. Turn the fan to the maximum position using the ON/OFF Dial



8. Place the grill rack on top



9. Turn the ON/OFF Dial from left to right to adjust the airflow to the desired setting

Guarantee

Our products are guaranteed for a period of 2 years from the date of purchase. Products that develop a fault within this period are covered by our warranty and we will replace defective parts, or where not available the whole product. The warranty does not apply to any defect in the goods arising from fair wear and tear, wilful damage, accident, negligence by you or any third party, use otherwise than as recommended by us, failure to follow our instructions, any alteration or repair carried out without our approval or has been the subject of commercial use. Your statutory rights remain unaffected, in particular any rights you have under the Consumer Rights Act 2015.

If you have a problem with your product within this warranty period please contact our customer services team.

In the event of changes to the specification of a product and we are not able to replace parts, we will replace the whole product within the 2 year guarantee period

For products that fall outside of the 2 year guarantee, we will endeavour to provide spare parts to purchase for as many of the replaceable parts as possible, but cannot foresee specification changes or upgrades to products or parts outside of the initial 2 year period.

Customer Services:

If you would like further advice or information on your product, ensure you have the SAP code ready and please get in touch with us at Fire Mountain on the contact options below:

SAP Code: JB03300201

Phone: 0330 002 1177 (Mon – Fri 9am to 5pm)

Email: support@fire-mountain.co.uk

Address: Fire Mountain, Vale Mill (Rochdale) Ltd, Robinson Street, Rochdale, OL16 1TA

DE

Vielen Dank, dass Sie sich für unseren Fire Mountain Holzkohlegrill mit Aktivbelüftung entschieden haben. Bitte lesen Sie sich diese Bedienungsanleitung sorgfältig durch und bewahren Sie diese zum späteren Nachschlagen auf. Wenn Sie Hilfe benötigen, wenden Sie sich bitte an unseren Kundendienst. Die Einzelheiten finden Sie auf der Rückseite dieses Handbuchs.

Warnungen und Hinweise

LESEN SIE DIE BEDIENUNGSANLEITUNG SORGFÄLTIG VOR DEM GEBRAUCH.

Dieses Produkt darf nur im Freien verwendet werden.

Verwenden Sie diesen Holzkohlegrill niemals in Innenräumen bzw. Geschlossenen Räumen, da brennende Holzkohle eine Kohlenmonoxidvergiftung verursachen kann.

Die maximal benötigte Menge an Holzkohle beträgt 250 g.

Grillen Sie nicht, bevor die Holzkohle leicht mit grauer Asche überzogen ist.

WARNUNG! Dieser Grill wird sehr heiß, bewegen Sie ihn nicht während des Betriebs.

Niemals in geschlossenen Räumen verwenden!

WARNUNG! Verwenden Sie keinen Spiritus oder Benzin zum Anzünden oder Wiederanzünden! Verwenden Sie nur Grillanzünder oder Grillpaste, die den Bestimmungen von EN 1860-3 entsprechen.

WARNUNG! Halten Sie Kinder und Haustiere fern.

Tragen Sie während des Grillens immer Grillhandschuhe, sowie wenn Sie die Lüftungsschlitze einstellen oder Grillanzünder verwenden.

Tragen Sie beim Zubereiten von Speisen und zum Hinzufügen von Holzkohle immer Grillhandschuhe.

Achtung: Wiederaufladbare Akkus können nicht verwendet werden.

Achtung: Um Verbrennungen zu vermeiden, tragen Sie immer Grillhandschuhe.

Achtung: Das Gerät wird während des Grillvorgangs sehr heiß, bitte tragen Sie immer Grillhandschuhe.

Produktspezifikationen

Einfaches und schnelles Anzünden mit intelligenter Aktivbelüftung.


Grillrost aus Edelstahl.

Das einzigartige Design des Holzkohlegrills verhindert, dass Fette und Gewürze in die Holzkohle tropfen.

Tragbares Design für Umzug und Lagerung.


Leicht zu reinigende Einzelteile.

Einzelteile




Hinweise zum Gebrauch


1. Legen Sie 4 AA-Batterien in das Batteriefach ein (nicht im Lieferumfang enthalten)




2. Füllen Sie den Holzkohlebehälter mit maximal 250 g Holzkohle



3. Geben sie Grillanzünder oder Brennpaste kreisförmig auf die Zündplatte




4. Setzen Sie die Batterie-Vorrichtung in die Basis des Hauptgrills sein




5. Grillanzünder oder Brennpaste mit einem langstieligen Feuerzeug oder Sicherheitsstreichhölzern anzünden




6. Stellen Sie den Holzkohlebehälter auf die Zündplatte



7. Drehen Sie den Aktivbelüfter mit dem EIN/AUS-Schalter auf die maximale Stufe



8. Platzieren Sie den Grillrost auf dem Grill



9. Drehen Sie den Ein/AUS-Schalter von links nach rechts, um den Luftstrom auf die gewünschte Stärke einzustellen

Garantie

Unsere Produkte unterliegen ab Kaufdatum einer Gewährleistungsfrist von 2 Jahren. Produkte, bei denen innerhalb dieses Zeitraums ein Fehler auftritt, sind von unserer Garantie abgedeckt. Wir ersetzen defekte Teile oder, sofern keine Ersatzteile verfügbar sind, das gesamte Produkt. Die Garantie gilt nicht für Mängel an der Ware, die auf normale Abnutzung, vorsätzliche Beschädigung, Unfall, Fahrlässigkeit von Ihnen oder Dritten, nicht von uns empfohlene Verwendungen, Nichtbeachtung unserer Anweisungen, durchgeführte Änderungen oder Reparaturen zurückzuführen sind, die nicht unserer Zustimmung entsprechen, oder falls das Produkt kommerziell genutzt wurde.

Sollten Sie während der Gewährleistungsfrist ein Problem mit unserem Produkt haben, wenden Sie sich bitte an unseren Kundendienst.

Wir ersetzen das gesamte Produkt innerhalb der Gewährleistungsfrist von zwei Jahren, sollten sich Änderungen bei der Spezifikation des Produktes ergeben oder für den Fall, dass wir keine Ersatzteile auf Lager haben.

Für Produkte, die außerhalb der 2-Jahres-Garantie liegen, sind wir bestrebt, Ersatzteile für möglichst viele der austauschbaren Teile bereitzustellen, können jedoch keine Änderungen oder Erneuerungen an Produkten oder Teilen außerhalb der ersten 2-Jahres-Frist vorhersehen.

Kundendienst:

Falls Sie weitere Informationen zu Ihrem Produkt benötigen, können Sie sich gerne unter der untenstehenden E-Mail Adresse an uns wenden:

SAP Code: DE_JK09045101

Email: support@vitinni.co.uk

Adresse: Delu Ako Minky GmbH, Hauptstraße 103, 53619 Rheinbreitbach